



No.:	Code:	Name:	No.:	Code:	Name:
1	617539	Screw	31	576148	Braket
2	617558	Bushing	32	617529	Pin
3	617504	Exhaust Cover	33	617485	Trigger Valve Unit
4	617533	Screw	34	617501	Trigger Unit Contact
5	617535	Washer	34	575850	Trigger Unit Sequential
6	576142	Cylinder Cap	35	576149	Nose Unit
7	617550	Gasket	36	576151	Screw
8	617548	Seal	37	576152	Workpiece Contact
9	617519	Spring	38	576154	Spring
10	617521	O-Ring	39	576155	Nose
11	617510	Valve	40	576157	Screw
12	617527	O-Ring	41	576158	Pusher Unit
13	617507	Stopper	42	576159	Magazine
14	617552	Collar	43	576160	Screw
15	617551	Cylinder Seal	44	576162	Pusher Lock
16	576143	Piston Unit	45	576164	Button
17	617523	O-Ring	46	576165	Spring
18	617505	Cylinder	47	576166	Spring
19	617524	O-Ring	48	576173	Magazine Cover Unit
20	617525	O-Ring	49	617549	Gasket
21	617503	Cylinder Ring	50	576167	Nut
22	617522	O-Ring	51	576168	End Cap
23	617506	Bumper	52	617534	Washer
24	576145	Insert	53	576169	Screw
25	576146	Body Unit	54	617509	Air Plug
26	617526	O-Ring	55	576177	Pin
27	617537	Pin	56	576170	Magazine Insert
28	617553	Guide	57	575849	Model Label Sequential
29	576147	Spring	57	575848	Model Label Contact
30	617498	Braket			