


J



No.:	Code:	Name:	No.:	Code:	Name:
1	617539	Screw	29	576147	Spring
2	617558	Bushing	30	617498	Braket
3	617504	Exhaust Cover	31	576148	Braket
4	617533	Screw	32	617529	Pin
5	617535	Washer	33	617485	Trigger Valve Unit
6	576142	Cylinder Cap	34	617501	Trigger Unit Contact
7	617550	Gasket	34	575856	Trigger Unit Sequential
8	617548	Seal	35	576150	Nose Unit
9	617519	Spring	36	576151	Screw
10	617521	O-Ring	37	576153	Workpiece Contact
11	617510	Valve	38	576154	Spring
12	617527	O-Ring	39	576156	Pusher Unit
13	617507	Stopper	40	576161	Screw
14	617552	Collar	41	576163	Pusher Lock
15	617551	Cylinder Seal	42	576164	Button
16	576144	Piston Unit	43	576165	Spring
17	617523	O-Ring	44	576166	Spring
18	617505	Cylinder	45	576174	Magazine Cover Unit
19	617524	O-Ring	46	617549	Gasket
20	617525	O-Ring	47	576167	Nut
21	617503	Cylinder Ring	48	576168	End Cap
22	617522	O-Ring	49	617534	Washer
23	617506	Bumper	50	576169	Screw
24	617508	Insert	51	617509	Air Plug
25	576146	Body Unit	52	576177	Pin
26	617526	O-Ring	53	576171	Magazine Insert
27	617537	Pin	54	575854	Model Label Contact
28	617553	Guide			