



No.	Code	Name	No.	Code	Name
1	617370	CAP ASM.	41	613122	ROLLED PIN
2	613071	SCREW	42	617657	PARALLEL KEY
3	574394	FRONT BRACKET	43	617660	BUMPER PLATE
4	617367	EXHAUST COVER	44	617661	DOOR BUMPER
5	617376	SCREW	45	617665	RUBBER PAD
6	613008	SPRING	46	617664	CHANNEL PLATE
7	613009	WASHER	47	617666	SPRING
8	613010	O-RING	48	617663	STAPLE GUIDE BLOCK
9	613011	PISTON HEAD VALVE	50	617662	INNER STAPLE GUIDANCE
10	613012	O-RING	51	617667	EXCENTER
11	613013	SEAL	52	617697	FRONT PLATE ASM.
12	613014	PLAIN WASHER	53	617698	DEPTH ADJUSTMENT ASM.
13	617369	PISTON STOPPER	54	617692	LOW STAPLE GUIDANCE
14	575680	CYLINDER COLLAR	55	617691	SCREW
15	617651	CYLINDER	56	613055	TRIP GUIDE
16	575677	O-RING	57	617677	SPRING
17	613114	CYLINDER RING	58	617678	UPPER SAFETY LEVER
18	617372	COLLAR	59	617654	SCREW
19	613022	O-RING	60	613433	FLAT WASHER
20	574403	GASKET	61	617655	MAGAZINE BRACKET
21	617373	BODY ASM.	62	617656	LOCK NUT
22	617652	BUMPER	63	617658	MAGAZINE COVER
23	613027	O-RING	64	617685	MAGAZINE
24	617696	DRIVER ASSEMBLY	65	617688	CLAMPING PLATE
25	617648	PISTON RING SET	66	617689	SCREW
26			67	617690	END SUPPORT
27	617659	SWITCH ASM.	68	617686	PUSHER GUIDE
28	613617	AIR PLUG	69	617687	SPIRAL SPRING ASM.
29	574400	SCREW	71	617680	MAGAZINE END CAP
30	574401	COVER	72	617681	STOPPER
31	574402	GASKET	73	613060	SPRING
32	613031	ROLLED PIN	74	617684	STEPPED PIN
33	575642	LOGO LABEL	75	613034	RETAIN RUBBER
34	617635	O-RING	76	617683	SPRING
35	617699	TRIGGER	77	617682	PUSHER RELEASE BUTTON
36	613053	SPRING	78	617695	MAGAZINE ASM.
38	617694	BASE ASM.	79	617700	MODEL LABEL
39	617653	BASE	80	617735	SPRING
40	617636	SCREW			